

2022/10/24

# Prelab 1

a)  $m_1$  of  $H_2O$  @  $T_1$  mixed with  $m_2$  of  $H_2O$  @  $T_2$ . Find  $T_f$

We know  $\Delta Q = mc\Delta T$ , so we can create two equations:

$$\Delta Q_1 = m_1 c (T_f - T_1) ; \Delta Q_2 = m_2 c (T_2 - T_f) ; \Delta Q_1 = \Delta Q_2 = \Delta Q$$

$$m_1 c (T_f - T_1) = m_2 c (T_2 - T_f)$$

$$T_f m_1 - T_1 m_1 - T_2 m_2 + T_f m_2 = T_f (m_1 + m_2) - T_1 m_1 - T_2 m_2 = 0$$

$$T_f = \frac{T_1 m_1 + T_2 m_2}{m_1 + m_2}$$

b)  $m_w$  of  $H_2O(l)$  @  $T_w$  mixed with  $m_{ice}$  of  $H_2O(s)$  @  $0^\circ C$ . Find  $T_f$

We know heat from one goes into the other:  $\Delta Q_1 = \Delta Q_2 = \Delta Q$

For heating water,  $\Delta Q = mc\Delta T$ . For melting ice,  $\Delta Q = mL_f$

$$m_w c (T_w - T_f) = m_{ice} c (T_f - 0) + m_{ice} L_f$$

$$\left. \begin{aligned} m_w c T_w - m_w c T_f &= m_{ice} c T_f + m_{ice} L_f \\ m_w c T_w - m_{ice} L_f &= T_f (m_{ice} c + m_w c) \end{aligned} \right\} \Rightarrow T_f = \frac{m_w c T_w - m_{ice} L_f}{m_{ice} c + m_w c}$$

c) Find  $L_f(c_w)$ .

$$\text{From (b): } m_w c T_w - m_w c T_f = m_{ice} c T_f + m_{ice} L_f$$

$$m_{ice} L_f + c(m_{ice} T_f + m_w T_f - m_w T_w) = 0$$

$$L_f = \frac{c(m_w T_w - m_{ice} T_f - m_w T_f)}{m_{ice}}$$

(d) Without ice starting at 0,  $T_{ic}$  doesn't go away, so

$$L_f = \frac{c(m_w T_w - m_{ice} T_f - m_w T_f + m_{ice} T_{ic})}{m_{ice}}$$


$$= \frac{c(m_w T_w - m_{ice} T_f - m_w T_f)}{m_{ice}} + \frac{m_{ice} T_{ic} \cdot c}{m_{ice}}$$

$$\alpha_{L_f} = \sqrt{\alpha_{T_{ic}}^2 \cdot \left(\frac{\partial L_f}{\partial T_{ic}}\right)^2} = \alpha_{T_{ic}} \cdot c = 2^\circ C \cdot 0.49 \frac{\text{cal}}{g^\circ C} = 0.98 \frac{\text{cal}}{g}$$

so it'll be  $\pm 0.98$  basically, assuming other quantities have no errors.

2022/10/24

### Prelab 2



$$\vec{q} = -k \vec{\nabla} T$$

$$H = -kA \frac{\partial T}{\partial x} = -kA \frac{T_i - T_o}{l}$$

$$\frac{\partial T}{\partial t} = \frac{k}{\rho c} \frac{\partial^2 T}{\partial x^2}$$

(a)  $H = -kA \cdot \frac{T_{out} - T_{in}}{l} = -k [2\pi r h + \pi r^2] \frac{T_{out} - T_{in}}{l}$   
↑ rate of heat flow out of the chamber

(b) temp change is  $\frac{dT_{in}}{dt}$ .  $\frac{dQ}{dt} = \frac{d}{dt} mc \Delta T = mc \frac{dT_{in}}{dt}$

$$H = -kA \frac{T_{out} - T_{in}}{l} = mc \frac{dT_{in}}{dt} = -k [2\pi r h + \pi r^2] \frac{T_{out} - T_{in}}{l}$$

$$\Rightarrow K = \frac{-mc l \cdot \frac{dT_{in}}{dt}}{(2\pi r h + \pi r^2) (T_{out} - T_{in})}$$


### Prelab 3

Just reading...


2022/10/24

## Experiment 1

We want to mix two different samples of water, at different temperatures. We will know the initial masses and temps of the water. We will mix them, then measure the temperature continuously until they reach equilibrium.



Stacked cups have mass of 10g when empty



Trial	g			$^\circ C$		
	$m_c$	$m_h$	$m_f$	$T_c$	$T_h$	$T_f$
1	$202 \pm 1$	$230 \pm 1$	$430 \pm 1$	$0.2 \pm 0.1$	$45.3 \pm 0.1$	$24.4 \pm 0.1$
2	$181 \pm 1$	$132 \pm 1$	$310 \pm 1$	$0.2 \pm 0.1$	$45.0 \pm 0.1$	$18.9 \pm 0.1$
3	$275 \pm 1$	$116 \pm 1$	$390 \pm 1$	$1.2 \pm 0.1$	$45.0 \pm 0.1$	$14.1 \pm 0.1$
4	$127 \pm 1$	$288 \pm 1$	$412 \pm 1$	$1.3 \pm 0.1$	$45.7 \pm 0.1$	$32.7 \pm 0.1$

2022/10/24

## Experiment 1

### Equipment

- 2x 2x 10g styrofoam cup
- tap water, distilled water
- ice
- Shelolab water heater
- mass scale
- water pitchers
- Logger Pro software
- Labquest-mini
- Vernier temp probe

### Procedure:

Heat water in bath to 50°C

Obtain ice and water in pitcher, wait for them to cool to 0°C

Fill one cup w/ cold water  $\frac{1}{3}$  of way, determine mass

Fill second cup w/ hot water  $\frac{1}{3}$  of way, find mass  
(no ice)

mix cups, observe probe reading on logger pro  
once equilibrium, record temp, record mass

2022/10/24

## Experiment 2

### Equipment:

- tub of ice
- shelolab water heater
- mass scale
- temperature probe
- logger pro software
- 2x 2x styrofoam cups
- labquest mini

### Procedure

collect ice in one cup, measure mass + temp

collect hot water in other cup, measure mass + temp

mix, wait for equilibrium, measure mass and temperature



$$m_h \cdot C \cdot \Delta T_h = m_c \cdot C \cdot \Delta T_c + m_c \cdot L$$

✓ ✓ ✓      ✓ ✓ ✓      ✓

cooling = heating + melting

$$L = \frac{C [m_h (T_f - T_h) - m_c (T_f - T_c)]}{m_c}$$

$$m_h c_w \Delta T_h = m_c c_w T_f + m_c L + m_c c_i (T_f - T_c)$$

$$L = \frac{m_h c_w (T_f - T_h) - m_c c_w T_f - m_c c_i (T_f - T_c)}{m_c}$$

2022/10/24

## Experiment 2

Trial	g			$\theta_C$		
	$m_c$	$m_h$	$m_f$	$T_c$	$T_h$	$T_f$
1	$65 \pm 1$	$156 \pm 1$	$218 \pm 1$	$-1.3 \pm 0.1$	$46.0 \pm 0.1$	$10.7 \pm 0.1$
2	$71 \pm 1$	$175 \pm 1$	$243 \pm 1$	$-1.3 \pm 0.1$	$45.7 \pm 0.1$	$11.9 \pm 0.1$
3	$89 \pm 1$	$308 \pm 1$	$339 \pm 1$	$-1.0 \pm 0.1$	$45.6 \pm 0.1$	$33.0 \pm 0.1$
4	$124 \pm 1$	$117 \pm 1$	$263 \pm 1$	$-1.4 \pm 0.1$	$45.3 \pm 0.1$	$-0.1 \pm 0.1$
	$+31 \pm 1$				$+45.3 \pm 0.1$	

2022/10/24

## Experiment 3a

Current Ambient Temperature:  $17.2 \pm 0.1^\circ\text{C}$

Cup:



Heat lost through base and sides

Thickness of base:  $0.20 \pm 0.01 \text{ cm}$

Thickness of sides:  $0.19 \pm 0.01 \text{ cm}$

Diameter of base:  $5.6 \pm 0.1 \text{ cm}$

Things to know:  $m$ ,  $m^2$ ,  $\dot{Q}T$ ,  $\Delta T$ ,  $\Delta t$

We have an ambient environment of known temperature:  
heat bath

Put cold water in a styrofoam cup, measure mass and temp

We put cup in bath matching internal and external heights

We put probe in cup and record data with logger pro

If we know how much the water in cup changes temp, we know how much it changes heat. We can look at this over time to find heat transfer/time as a function of  $\Delta T$ .

### Equipment

- shel lab water heater
- 2x 2x styrofoam cups
- mass scale
- temperature probe
- labquest mini
- logger pro software

2022/10/24

### Experiment 3a

#### Procedure:

We fill a styrofoam cup w/ tap water up to a height  $h$ ,  
We place the temperature probe in the cup, then place the cup in the heat bath, holding it down against the bottom.  
We know the dimensions of the cup, so we can export data from logger pro to find heat flow.

Trial 1 (short) height:  $5 \pm 0.3$  cm  $m_w = 121 \pm 1$  g

Trial 2 (long) height:  $10.3 \pm 0.3$  cm  $m_w = 350 \pm 1$  g  
 $T_{out} = 46.7^\circ\text{C}$

To measure the mass, we put it on the scale and subtracted the cup mass (5g). To measure height we held it to the light

### Experiment 3c

We follow the same procedure as 3a, swapping the styrofoam cup for the metal can. Can mass:  $45 \pm 1$  g

To measure water height we put our finger in, then measured the waterline.

$$m_c \frac{dT}{dz} = \frac{kA}{L} (T - T_0) \quad m_c \frac{dT}{dt} = \frac{kA}{L} \Delta T$$

$$\frac{dT}{dt} = \gamma \Delta T \Rightarrow \Delta T = \Delta T_0 e^{-\gamma t}$$

Trial 1 (short)  $m_w = 131 \pm 1$  g  $h = 3.5 \pm 0.3$  cm

Trial 2 (long)  $m_w = 185 \pm 1$  g  $h = 5.7 \pm 0.3$  cm



2022/10/24

## Experiment 4